

CUBE EAVE INSTALLATION INSTRUCTIONS



NOTE: THESE INSTRUCTIONS MUST NOT CONTRAVENE YOUR LOCAL ELECTRICAL AUTHORITY REGULATIONS, WITH WHICH ALL INSTRUCTIONS HERE IN MUST COMPLY. PLEASE KEEP INSTRUCTIONS FOR FUTURE REFERENCE.

Fixtures require 3Vf @1050mA constant current Max. (350mA constant current is recommended)

Fixture to wired in series only.

Cut a neat 40 x 40mm square hole in the surface you wish to mount into. Alternatively you can use a 50mm hole saw.

Draw power supply cable down through the cut hole and make a good electrical connection with the fixture input cables. See diagram for correct wiring. Be sure to leave extra length to allow the fixture to be removed from the ceiling without disconnection for servicing.



Once electrical connections have been made fold back the springs and insert through cut hole into the ceiling cavity. The springs should snap into place and hold the fixture securely to the surface.

